



GigRig Pedalboards Manual

CONTENTS


1. INTRODUCTION
2. WHAT'S INCLUDED?
3. SINGLE TIER
4. WAH WALL
5. DOUBLE TIER PEDALBOARD
6. SIDE ACCESS PORTS
7. CASE LID
8. DIMENSIONS OF EACH SIZE
9. THE GIGRIG PEDALBOARD GIG BAG
10. WARRANTY

1. INTRODUCTION

We believe that a pedalboard should be functional, practical, tour-worthy—and, of course, great to look at! We set out to design a range of pedalboards that address common issues when using a switching system. After a bit of inspiration and two years of constant refinement, we're delighted to introduce our range of GigRig Pedalboards.

It might seem a little unusual to receive a manual for a pedalboard, but with our design, the possibilities are endless. We want to give you some inspiration and get you thinking about how to set up your board to do exactly what you need it to do.

2. WHAT'S INCLUDED?



All pedalboards now ship with our 'modesty panel' pre-fitted. These panels are removable. See below for an example of how they look.





3. SINGLE TIER PEDALBOARDS




TheGigRig Single Tier pedalboards are perfect for compact setups. They consist of a single tier giving you the option of hinging from either the front or the back.

The Single Tier boards have 4 access ports, 2 on each side, with removable side panels designed for our Cinco Cinco patch bay or Three2One input selector.



The Single Tier can either hinge from the back, or the front. To change the hinge direction simply pull back on the spring latches to remove the tier, then unscrew the tier pin and relocate it to the back. It's super simple and offers flexibility never before seen in a pedalboard solution.



4. WAH WALL



The Wah Wall enables you to add a wah or an expression pedal to your pedalboard.

How to convert from a standard tier to the wah wall



Remove the standard tier and place the 10MM M3 screws (provided) into the Wah Riser.



Choose the side you want to place your wah or expression pedal and attach the Wah Riser to the pedalboard using a Phillips head screwdriver. The Wah Riser is now in place. It's time to connect the Wah Wall.



Set the pedalboard on end so you can easily access the underside of the board where you'll need to thread some screws to attach the Wah Wall.



Using the M4 20MM screws and extra feet (provided) connect the Wah Wall to the pedalboard by threading the screw through the feet and placing screw through the underside of the pedalboard. The screws will thread into the Wah Wall.



The Wah Wall is now attached. Now attach the Tier Pin either on the front or back depending on where you want to board to hinge. Its standard to hinge the tier from the back but both options are available.



Now, simply attach the smaller tier (included) and you have your Wah Wall. The holes in the Wah Riser are pre drilled and fit many of the most popular wah and expression pedals.

Wah Riser dimensions:
Width: 11cm / 4.33"
Length: 26cm / 10.23"


5. DOUBLE TIER PEDALBOARDS


TheGigRig Double Tier Pedalboards include all the same design features as the Single Tier boards, with the addition of a very clever front tier

The front tier can be set on the different levels giving you some options for height positioning making it easy to access pedal on both the front and rear tiers.

The front tier also includes our very own Lift/Slide system where the tier is on rails so you can lift the front edge then slide it out of the way giving you access to everything underneath the front tier without having to move the back tier

The Lift/Slide function of the front tier is retained when using the Wah Wall





6. SIDE ACCESS PORTS



The Side Access Ports on TheGigRig Pedalboards give you all the options you need to connect your input and output signals. Simply unscrew the screws holding the port plates and you can then place your Cinco Cinco patch bay, GigRig power supply, Three2One input selector, anything that you want easy access to on the side panel.

To attach other GigRig products we recommended Nano Grab Gel Tape or Pedalboard Tape, both available at our store.



Cinco Cinco



Three2One Input Selector on a Medium Single

Blanking plate hole size:

Length: 10.5cm / 4.13"

Height: 3cm / 1.18"

7. CASE LID



A welcome part of the design TheGigRig Pedalboards is the foam lined Case Lid. Each pedalboard comes with a case lid included which effectively turns your pedalboard into a travel case. Simply hook the case lid back to the back of the pedalboard and close the lid using the butterfly clasps and you're ready to go.

8. DIMENSIONS

TheGigRig Pedalboards are available in 5 different sizes

Small Single Tier

Weight: 1.35kg / 2.97lb

Dimensions: No Lid

H: 12cm / 4.72"

W: 33.1cm / 13.3"

Depth: 33.5cm / 13.18"

Dimensions: Including Case Lid

H: 19.8cm / 7.79"

W: 34cm / 13.38"

Depth: 33.5cm / 13.97"

Included in order:

1 x Board base

1 x Shell case lid

1 x Small wide tier

1 x Modesty Panel

1 x Allen Key



Medium Single Tier

Weight: 2.80kg / 6.17lb

Dimensions: No Lid

H: 12cm / 4.72"

W: 46cm / 18.11"

Depth: 33.5cm / 13.18"

Dimensions: Including Case Lid

H: 19.8cm / 7.79"

W: 47cm / 18.5"

Depth: 35.5cm / 13.97"



Included in order:

- 1 x Board base
- 1 x Shell case lid
- 1 x Full length wide tier
- 1 x Small wide tier
- 1 x Wide wah wall
- 1 x Wah riser
- 1 x Modesty Panel
- 2 x Rubber feet for underneath Wah Wall
- 2 x Screws for rubber feet
- 2 x Wah Riser screws
- 1 x Allen Key

Medium Double Tier

Weight: 3.45kg / 7.60lb

Dimensions: No Lid

H: 12cm / 4.72"

W: 46cm / 18.11"

Depth: 48.6cm / 19.1"

Dimensions: Including Case Lid

H: 19.18cm / 7.79"

W: 47cm / 18.5"

Depth: 50.5cm / 19.8"

Included in order

- 1 x Board base
- 1 x Shell Case Lid
- 1 x Medium wide tier
- 1 x Medium narrow tier
- 1 x Small narrow tier
- 1 x Narrow Wah wall
- 1 x Wah riser
- 1 x Modesty panel
- 2 x Rubber feet for underneath Wah Wall
- 2 x Screws for rubber feet
- 2 x Wah Riser screws
- 1 x Allen Key



Large Single Tier

Weight: 4.8kg / 10.58lb

Dimensions: No Lid

H: 12cm / 4.72"

W: 59.3cm / 23.34"

Depth: 33.5cm / 13.18"

Dimensions: Including Case Lid

H: 19.8cm / 7.79"

W: 60cm / 23.62"

Depth: 35.5cm / 13.97"



Included in order

- 1 x Board base
- 1 x Shell case lid
- 1 x Large wide tier
- 1 x Medium wide tier
- 1 x Wah wall
- 1 x Wah riser
- 1 x Modesty Panel

Ships with

- 2 x Rubber feet for underneath Wah Wall
- 2 x Screws for rubber feet
- 2 x Wah Riser screws
- 1 x Allen Key

Large Double Tier

Weight: 5kg / 11.02lb

Dimensions: No Lid

H: 12cm / 4.72"

W: 59.3cm / 23.3"

Depth: 48.6cm / 19.1"

Dimensions: Including Case Lid

H: 19.8cm / 7.79"

W: 60cm / 23.6"

Depth: 50.5cm / 19.8"

Included in order

- 1 x Board base
- 1 x Shell case lid
- 1 x Large wide tier
- 1 x Large narrow tier
- 1 x Medium narrow tier
- 1 x Narrow Wah wall
- 1 x Wah riser
- 1 x Modesty panel
- 2 x Rubber feet for underneath Wah Wall
- 2 x Screws for rubber feet
- 2 x Wah Riser screws
- 1 x Allen Key




9. The GigRig Pedalboard Gig Bag

At TheGigRig, our team is made up of musicians who regularly play live, so we know firsthand the challenges of transporting gear. That's why the GigBag was a key part of our pedalboard design.

One of the biggest frustrations with many gig bags is the front pocket—while useful for storage, its bulky design makes flat-packing impossible. If you've ever packed your rig into a car or van, you know that every bit of space matters.

The TheGigRig Pedalboard GigBag solves this problem by integrating the pocket within the negative space inside the bag, allowing you to store your cables and accessories without adding extra bulk. This means you get all the storage you need while still retaining a compact, flat-pack design—perfect for efficient load-ins and travel.



WARRANTY

The GigRig warrants this product to be free from defects in material and workmanship for **12 months** (or legal standard for country of delivery) from the date of original purchase.

If the product fails within the warranty period, The GigRig will repair or replace it at our discretion and cover return shipping. This warranty applies when used as recommended. It does not cover:

- Loss, theft, misuse, abuse
- Unauthorized modification or improper storage
- Lightning or natural disasters

Damage from the above may incur a non-warranty repair fee.

This warranty is not transferable to a new owner should you sell the pedal.

Legal:

In the event of malfunction, the purchaser's sole remedy is repair or replacement. The GigRig is not liable for:

- Lost profits or savings
- Damage to other equipment
- Incidental or consequential damages

The GigRig's liability will not exceed the original purchase price. All warranties other than those expressly stated are disclaimed.

Disposal:

No batteries or lead inside. Return to TheGigRig Ltd or follow local electrical disposal regulations. Do not dispose of in household waste.

Copyright & Legal

- TheGigRig is protected by copyright, patent, and design registration.
- 'GigRig' is a registered trademark (No. 2343300).
- Unauthorized copying of design or functionality for commercial gain may lead to legal action.
- Licenses may be granted to non-competing companies.

Compliance:

- RoHS Compliant
- Compliant with EN 60950
- Power supply approved for USA and EU regulations (see separate instructions)

Manufacturer:

The GigRig Ltd, Unit 15 Whitehill Industrial Pk, Royal Wootton Bassett, SN4 7DB

Authorised Representative:

EAS – Mustamäe tee 50, 10621 Tallinn, Estonia

Warnings:

For indoor use only. Keep away from water and children



**CE UK
CA RoHS**